



LIVING ROOM DIY PROJECT

PRIMER HAS A MILDEW RESISTANT PRIMER FINISH

SUPPLYLIST

- Primer: KILZ® Kitchen & Bath
- Paint: KILZ Complete Coat®
 - Walls – White RJ110
 - Fireplace – Swiss Coffee LJ240A
- 3/8"-1/2" Nap Paint Roller
- Paint Brush
- Drop Cloth
- Tape
- Damp Cloth
- Can Key
- Stir Stick



FIREPLACE

1 First, you'll want to clean the old brick fireplace. If it's extra dirty, start with a vacuum and use the crevice tool attachment to clean between the bricks. Next, wipe down the fireplace with a damp cloth to ensure all surfaces are clean and free of any lingering dust. Allow to dry.



2 Tape around the fireplace to protect the walls and floor. Also tape around the mantel and where the brick meets the firebox (the inside where the wood goes!) to keep that area protected from paint and primer.



3 Now it's time to prime! Using KILZ 2® All-Purpose primer, start with an angled brush to cut in around the mantel.



4 Next, use a roller to cover the brick faces with primer. If needed, go back with a small angled brush to fill in any remaining grout areas. Allow to dry.



5 Once your primer is dry, apply KILZ Complete Coat® in Swiss Coffee using the same application method as the primer (use a brush first to cut in and then use a roller).

6 Remove the painter's tape before your paint is fully dry.

Always remember to refer to our website kilz.com or product back labels for additional information on which primer is right for your project and detailed instructions on how to apply our products.