



DIY PROJECT REFRESH A DRESSER

SUPPLY LIST

- | | | |
|--|---|---|
| <input type="checkbox"/> KILZ® Original Primer | <input type="checkbox"/> Screwdriver | <input type="checkbox"/> Stir Stick |
| <input type="checkbox"/> Paint | <input type="checkbox"/> 100-150 Grit Sandpaper | <input type="checkbox"/> Damp Cloth |
| <input type="checkbox"/> Drop Cloth | <input type="checkbox"/> 180-220 Grit Sandpaper | <input type="checkbox"/> Painter's Tape |
| <input type="checkbox"/> 4 Bricks | <input type="checkbox"/> Paint Brush | <input type="checkbox"/> Paint Tray |
| <input type="checkbox"/> 6 mm Nap Paint Roller | <input type="checkbox"/> Can Key | |



PRO TIP: When sanding, move the sandpaper in the same direction of the wood grain. If you go against the grain you will end up with a lot of nasty scratches that will show through your topcoat.



PRO TIP: To get better coverage along the bottom of the drawer faces, raise them up off your work surface with bricks.

RESULT



1 Use your screwdriver to remove drawers and hardware. It's always best to put every screw back exactly where it came from. That will put the least amount of stress on the wood.

PRO TIP: Put the screws back into the hardware, then seal the hardware and screws in painter's tape and label it.

2 Sand the surface. Sanding everything well is the right way to do it. Sanding will create smooth surfaces on the drawer faces and dresser body, and that will help your paint look great. When sanding, do a first pass with 100-150 grit sandpaper then finish with a second pass of 180-220 grit sandpaper. Remember, the higher the "grit" number, the smoother the finish.

3 After sanding, wipe down the surface with a damp cloth to remove any dust or residue. Primer and paint won't stick to dust. After wiping, allow the surface to dry before moving on to primer.

4 Apply a primer. When painting wood furniture you should always use a primer first. Primer will help protect the wood, and it will also create a smooth base to help you get better adhesion and truer colour from your paint. When applying primer, just as you did with the sandpaper, move in the same direction as the wood grain for best results.

5 Allow 2 hours for the primer to dry.

6 Apply your paint exactly the same way you applied your primer. Always paint in smooth strokes that go in the same direction as the wood grain.

PRO TIP: For extra fun, try an accent colour on the drawer faces.

7 Allow 2 hours dry time*, then apply second coat.

8 Reattach your hardware and voilà! It's time to take a break and totally procrastinate folding laundry and putting all your clothes away.

*Dark colours and high humidity areas may have extended dry times